



GATEWAY ML6720 Battery Replacement

Detailed steps on how to replace the laptop's battery.

Written By: Nathan Da Silva




Step 1 — Battery



- Flip the laptop on to the backside.

Step 2



- Locate the battery at the very top on the backside of the laptop.

Step 3





- Slide the latch in the top right corner to the right, to set it to unlocked.

Step 4



- Hold the other latch in the top left corner to the left.
- hold it in that place with your thumb until the completion of the next step. (This step unlocks the second latch.)

Step 5



- With both latches unlocked you can now slide out the battery, by pushing it off the top.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 12:41:54 AM.